

# OVERVIEW

- Adds Cymbal to Setup without Stand
  - 360-Degree Gyro-Lock Tilter
  - Memory Locks
  - Won't Get in Way of Other Equipment
- 

## ITEM DETAILS

This Pearl CH1030B Gyro-Lock Boom Cymbal Holder can be attached to any other piece of hardware, giving you the ability to add a cymbal to your setup without needing an entire stand. The hideaway boom arm is short, so it won't get in the way of other equipment or make your setup look silly.

The Gyro-Lock tilter at the end of the boom arm offers you complete 360-degree angle adjustment for absolute positioning freedom. Memory locks on the main downtube and the boom arm let you put the stand in exactly the same position from gig to gig within seconds.